## **Group Setup Checklist - 2017A**

## **Case Inventory**

|                | E D7000 0 D 1 (0 E : 1 (0 )  |
|----------------|--|
| Camera         | □ D7200 Camera Body (Or Equivalent Camera)   |
|                | ☐ 18-105mm Lens  |
| ₹              | ☐ Lens Hood  |
| 3              | ☐ 2 Genuine Nikon Camera Batteries - Charged   |
| B              | ☐ Camera Battery Charger   |
|                |  |
|                | ☐ 1 Heavy Duty Light Stand   |
| <u></u>        | □ 2 Alien Bee B800's/Einstein's  |
| <del>J</del> h | □ 2 Power Cords - Short  |
| <b>=</b> :     |  |
| Lighting       | ☐ Studio Lights Tested   |
| <u>u</u>       | ☐ 2 1/4" Stereo Sync Cords   |
|                | ☐ 2 Hot Shoe Adapters  |
|                | ☐ 2 CyberSync Transmitters   |
|                | ☐ 2 CyberSync Receivers  |
|                | ☐ 2 CyberSync Sync Cords – Miniature to ¼"   |
|                | ☐ (1) 60" White Umbrella   |
|                | ☐ Light Meter – Battery Checked  |
|                | ☐ 2 Power Strips & Extension Cords   |
|                | ☐ 2 Vagabond Power Packs – Charged (Optional)  |
|                |  |
|                | П  |
|                |  |
|                |  |
|                |  |
| $\dashv$       | ☐ PhotoMatch Tablet - Charged  |
|                |  |
| ab             | ☐ Keyboard   |
| able           | ☐ Keyboard ☐ Power Cord  |
| ablet          | 7  |
| ablet K        | □ Power Cord   |
| Tablet Kit     | ☐ Power Cord ☐ Tablet Bracket to Mount on Stand  |
| ablet Kit      | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables   |
| ablet Kit      | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners   |
| ablet Kit      | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router   |
| ablet Kit      | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □   |
| ablet Kit      | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router   |
| ablet Kit      | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ 2 Memory Cards □ Memory Card Envelopes  |
| ablet Kit Misc | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ 2 Memory Cards □ Memory Card Envelopes  |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ □ 2 Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch  |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ 2 Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ □ □ Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure □ Gaffer Tape   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ □ □ 2 Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure □ Gaffer Tape □ Hoodman Viewer (Optional) □ Stool   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ □ Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure □ Gaffer Tape □ Hoodman Viewer (Optional) □ Stool □ Photo Props   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ 2 Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure □ Gaffer Tape □ Hoodman Viewer (Optional) □ Stool □ Photo Props □ BU Sequence Cards, Stringer, Pens   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure □ Gaffer Tape □ Hoodman Viewer (Optional) □ Stool □ Photo Props □ Registration/Ordering Tablets – Charged   |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ □ □ □ 2 Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure □ Gaffer Tape □ Hoodman Viewer (Optional) □ Stool □ Photo Props □ BU Sequence Cards, Stringer, Pens □ Registration/Ordering Tablets – Charged □ 10x20 (minimum) Chroma-Key Green Background |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ 2 Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure □ Gaffer Tape □ Hoodman Viewer (Optional) □ Stool □ Photo Props □ BU Sequence Cards, Stringer, Pens □ Registration/Ordering Tablets – Charged □ 10x20 (minimum) Chroma-Key Green Background       |
|                | □ Power Cord □ Tablet Bracket to Mount on Stand □ (2) D7100/7200 Camera USB Cables □ Double USB Adapter □ 2 Scanners □ Hot Spot Router □ □ □ □ □ □ □ 2 Memory Cards □ Memory Card Envelopes □ Zippered Card Pouch □ Tape Measure □ Gaffer Tape □ Hoodman Viewer (Optional) □ Stool □ Photo Props □ BU Sequence Cards, Stringer, Pens □ Registration/Ordering Tablets – Charged □ 10x20 (minimum) Chroma-Key Green Background |

## **Setup & Settings**

☐ Setup Background so Subject Exposure is Minimized ☐ Mark spot for Group Back Row (4ft from Background) ☐ Mark Position with Tape ☐ Mark Spot for Main Light at 12ft from Group ☐ Setup Main Light with 60" White Umbrella (No Reflector) ☐ Bottom of Reflector 5ft from Floor ☐ Point Light/Umbrella Towards Group Position ☐ Power up Studio Light (AC Power or Vagabond) ☐ Modeling light/bulb is OFF (If Using Vagabond) ☐ Set Light Meter to: "Flash", ISO 400, Shutter 125 ☐ Stand in Group Position to Take Meter Reading ☐ Point Light Meter Towards Main Light Position ☐ Hit "Reset" Button on Meter and Take Reading ☐ Adjust Power Setting of Light Until F/8 is Achieved ☐ Set Up Tripod & Camera ☐ Verify Camera Settings: ☐ Camera Shutter Speed: 1/125<sup>th</sup> ☐ Camera ISO: 400 ☐ Camera Aperture (f/stop): **Set to Overall Reading** ☐ Camera Shooting Mode: M (Manual) ☐ Camera Image Size: M (Medium) ☐ Camera Image Quality: Basic ☐ Camera White Balance: Flash ☐ Camera Shutter Release Mode: S (Single) ☐ Camera Body Focus Mode: AF ☐ Lens Focus Mode: A or MA (NOT M) ☐ Camera Focus Mode: AF-S (Single) ☐ Camera Auto Focus Points Area Mode: Auto ☐ Camera Image Review Settings: Focus Points On ☐ Camera Review Mode: Focus Points Screen ☐ Front of Lens Clean & Lens Hood Properly Seated ☐ Mount CyberSync Transmitter on camera ☐ Take Test Shot – Confirm Proper Exposure ☐ Set Up Hot Spot & Tablet ☐ Verify Tablet is Working Properly